


Horten Ho 229 V3

All Wood Short Kit



a Radio Controlled Model
in 1/8 Scale

Design by Gary Hethcoat

Copyright 2007

Aviation Research

P.O. Box 9192, San Jose, CA 95157

<http://www.wingsontheweb.com>

Email: gary.hethcoat@gmail.com

Phone: 408-660-0943

Table of Contents

1	General Building Notes	4
1.1	Getting Help	4
1.2	Laser Cut Parts	4
1.3	Electronics	4
1.4	Building Options	4
1.4.1	Removable Outer Wing Panels	4
1.4.2	Drag Rudders	4
1.4.3	Retracts	5
1.4.4	Frise Style Elevons	5
1.5	Motor/Speed Controller Choices	5
2	Center Section (All Wood Version)	6
2.1	Front Spar and Ribs	6
2.2	Battery Mounting Method	8
2.3	Rib Mid-Sections	9
2.4	Retract Installation	11
2.5	Rear Rib Sections	12
2.6	Upper Center Section Stringers	13
2.7	Leading Edge Installation	14
2.8	Intake Duct Installation	14
2.9	Rear Duct Fairing	15
2.10	Sheeting the Upper Center Section	15
2.11	Strip Planking the Engine Covers and Canopy Area	16
3	Outer Wing Panels	18
3.1	Laminating the Rib Doublers	18
3.2	Laying Down the Ribs	19
3.2.1	Elevon Servo Conduit	20
3.2.2	Drag Rudders	20
3.3	Installing the Laminated Spars	21
3.4	Leading Edge & Sheeting	23
4	Completing the Outer Wing Panels	27
4.1	Upper Center Section Jig	27
4.2	Fitting the panels	27
4.3	Determining Attachment Method	27
4.4	Jigging the Outer Wing Panels	27
4.5	Elevon Servo Installation	29
4.6	Drag Rudder Construction (optional)	32
4.7	Lower Outer Wing Panel Sheeting	36
5	Installing Fans & Electronics	37
5.1	Fans	37
5.2	Batteries	38
5.3	Connecting it all Together	39
5.3.1	Battery Connection	40
5.3.2	Rear Duct	41
6	Lower Center Section	42
6.1	Lower Center Section Sheeting	42

6.2 Wing Tips.....	44
6.3 Cutting out and Hinging the Frise-style Elevons	44
6.4 Flap Construction (optional).....	46
7 Finishing.....	48
7.1 Finishing the Center Section	48
7.2 Finishing the Outer Wing Panels.....	48
7.3 Paint & Markings	48
8 Trimming for Flight.....	50
8.1 Extension Tubes.....	50
8.2 Center of Gravity.....	51
8.3 Balancing Method	51
8.4 Recommended Control Throws.....	53
8.5 Ground Sit (ROG version).....	53
9 Flying the Ho 229.....	54
9.1 General Flying Characteristics	54
9.2 Aerobatics.....	54
9.3 Bungee Flying	54
9.4 Flying from a runway (ROG).....	54
9.4.1 Takeoff Procedures (ROG version)	55
9.5 Approach and Landing	55
9.6 More Info.....	55
9.6.1 RCSB Thread.....	55
9.6.2 Yahoo Group “Ho229”	55
9.6.3 Ezone Thread.....	55
9.6.4 Phone and “Snail Mail”	56

1 General Building Notes

This model features mostly conventional construction methods and so should present few problems to the experienced builder. This is not a beginner's model. If you have limited building and flying experience, it is strongly recommended that you start with a more appropriate model and work up to the Ho 229.

1.1 Getting Help

If you need help or advice, please don't hesitate to contact us. Email and phone are listed on the title page.

1.2 Laser Cut Parts

Most of the laser cut parts can be gently broken free of the sheet. Be careful, though, some parts will come out cleaner if you cut through the little "breaks" with a hobby knife before removing the part from the sheet. This is particularly true of the lightening holes in the ribs.

1.3 Electronics

If this is your first high-powered electric model, proceed with extreme caution when handling, soldering and connecting batteries and speed controllers. A short or reversed connection can **FRY** some very delicate and expensive equipment! When soldering connectors onto LiPo batteries, work with one wire at a time and make sure the other is well insulated. Shorting these batteries will cause damage, and it is very easy to do if you work with both wires at the same time. Make absolutely sure you have the connections right before applying battery power to the speed controller.

1.4 Building Options

1.4.1 Removable Outer Wing Panels

The all wood model wasn't really designed for removable outer wing panels. It can be done, but will require some extra work and added weight. If you want to go that route, contact us and we can advise you. You will have less work and a lighter model if you attach them permanently.

1.4.2 Drag Rudders

The outer drag rudders used on the full size are shown on the plans. They are advisable if you plan to build a ROG version to be used on a narrow runway. These are your only method of controlling the model's flightpath in a crosswind landing on a runway.

1.4.3 Retracts

Keep in mind that retracts will add significantly to the finished weight. There is a CG shift to consider as the nose wheel retracts.

1.4.4 Frise Style Elevons

See the plans. These have been used on the prototype model. It is believed they offer some advantage in turning. However, experience has shown them to be quite vulnerable to damage when belly landing on grass. They tend to catch in the grass. I would recommend these only for an ROG model.

1.5 Motor/Speed Controller Choices

The model was designed around the Wemotec Mini-fan 480 (69mm) units. There are similarly sized units available from other manufacturers also. The duct brackets are designed for this size fan, though, so make sure whatever you use has the exact same inside diameter as these units. The prototype used the HET-RC Typhoon EDF 2W-20 (700 Watt) motors and SPT 80 Amp controllers. A good source for fans, motors and speed controllers is Warbirds-RC.com, <http://www.warbirds-rc.com/>. They have good prices and we've received excellent service from them.

Building Guide Photos

Some of the photos may not be all that clear in the printed building guide. A downloadable PDF version of the guide is available on the Yahoo group (see references at the end of this document). The photos are clearer when viewed on a computer.

2 Center Section (All Wood Version)

2.1 Front Spar and Ribs




Figure 1: Front center section rib installation

Start by dry fitting the front ribs to the forward carry-through spar. Test fit the fan shroud in place. Rib 0 looks different in the pictures from the production parts. Blocks should be installed on the outside edges of ribs 1 and 2A to accommodate the hold-down screws that mount the fan unit. We chose to use 1/4" spruce, with self-tapping screws to hold the fans in place. You should also test fit the front duct brackets DB1 and DB2 at this time and plan the intake duct installation. The intake duct can be made of sheet plastic, 1/64 ply or fliteskin. You should choose a material that will bond well with whatever filler you will use around it to achieve a rounded front lip.

A smooth, well rounded intake lip is important for efficient air flow into the duct. Keep in mind also that the front duct will tuck **inside** the front of the shroud unit. See the plans. Before going any further, assemble one of the fan and speed controller units and test fit them in place. See Figure 2.




Figure 2: Fan and speed controller assembly

The speed controller and motor housing extend behind the shroud. It's important to keep this in mind

when planning fan installation and access.

2.2 Battery Mounting Method

There are two ways to mount the LiPo batteries. A laser cut battery tray is provided. It fits between ribs #1. It can be secured with screws or velcro. An alternate method is to simply fasten the batteries directly to ribs #1 with velcro. If you choose this method, it is advisable to fasten the velcro to ribs #1 now, while access is easy. It will be harder to do later once the remaining ribs and formers are in place. The sticky-back velcro will not adhere to wood. One way is to glue some thin sheet plastic to the ribs with thick CA. The velcro will adhere to the sheet plastic. See Figure 3. The photo below is just an example to give you an idea. This photo is of the fiberglass center section parts, so they look a little different from what you have. Some additional velcro aft of the main spar can be used for radio installation.




Figure 3: Velcro installation on Ribs 1

When you're satisfied with the installation, glue the forward ribs to the forward spar using a square for alignment. Two passes with thin CA and then a bead of thick CA will produce a good bond with the lite ply parts.

2.3 Rib Mid-Sections



Figure 4: Rib Mid-Section Installation

Dry fit the rib mid-sections to the rear carry-through spar. Test fit the rear duct brackets DB2 & DB3 between ribs 1 & 2A. Glue the ribs to the rear carry-through spar, and the duct brackets to the ribs. Use a square to ensure the ribs are square to the spar. If you plan to bungee launch the model, install the keel doublers as shown on the plans.

Now assemble the center section lower jig as shown over the plans, aligning it carefully over sections C-C and E-E.




Figure 5: Lower Center Section Alignment Jig

Now attach the front rib assembly to the mid-rib assembly and glue it all together. Make sure the jig pieces are firmly attached to the building board. Tack glue the front and rear carry-through spars to the jig pieces. This will insure the center section is in correct alignment as you finish installing the ribs and sheet the top. The assembly should now look something like Figure 6. You can also begin gluing in the 1/8" formers as shown.





Figure 6: Front and Center Rib Installation

2.4 Retract Installation

Retracts have to be considered experimental in this model since they haven't been flight tested. Parts are provided, but we can only offer limited instruction since we currently have no experience with their application. Several people have begun working with retracts for this model, and updates will be posted to RCSCALEBUILDER.com and the Yahoo group as progress is made.

The main retract units are mounted to the Main Retractable Plates (labeled MRP), these fit between ribs 2A and 3A as shown below. The retract formers F-F-R and G-G-R support the main retract plate.



The MRP pieces are marked with a small crosshair to show the location of the scale strut. You may have to offset this slightly depending on the retract units chosen. We have chosen Spring Air retracts since they are lightweight, sturdy and relatively inexpensive. We're using the 603 units for the mains and the 706 unit for the nosegear. The nosegear retract plate (NRP) is sized to fit between ribs #1. See the plans for scale strut location. Both this and the main retract plates have to be cut out to fit the retract units of your choice. The NRP should be reinforced with triangle stock.

You must also take into account the CG shift when the nosegear retracts. Balance the model with the gear retracted.

2.5 Rear Rib Sections

Figure 7 shows the rear rib section installation. Use a square to align the ribs over the plans. Use the 1/64" ply trailing edge pieces to help align the ribs.




Figure 7: Installing the Rear Rib Sections

You can slide rib #3A over the spars now and glue it to the spars. Use a straight edge against rib #3A on both sides to ensure they are both straight. These will be your mating surfaces for the outer wing panels. Glue them to the 1/64" ply trailing edge pieces also. Once everything is aligned and all the 1/8" formers are in place, you are ready to finish the upper surface.

2.6 Upper Center Section Stringers

The first step is to glue in the 1/8" square stringers for the engine covers. These should make a smooth curve from front to rear, with no 'breaks' at the formers. Fit them in place dry and tack the ends first.




Figure 8: Engine Cover Stringers

These stringers will serve as a guide for strip planking this area. To get the right scale shape, it is important that these form a smooth curve.



Figure 9: Stringer Curvature

2.7 Leading Edge Installation

Next we install the 1/4" x 1" balsa leading edges as shown in Figure 10.




Figure 10: Leading Edge Installation

2.8 Intake Duct Installation

Figure 11 shows the intake duct installation. You can use a variety of materials for the intake duct. Just be sure whatever you use will bond well with the filler you plan to use around the joint with the center section. You need to make a nice rounded lip on the intake to get efficient airflow into the duct. The material should also be strong enough not to collapse from the air pressure from the fan.




Figure 11: Intake Duct Installation

2.9 Rear Duct Fairing




Figure 12: Rear Duct Fairing

The rear duct is not permanently installed. It will be rolled/folded and slipped into the brackets and secured to the fan shroud with tape. You need a fairing for the aft portion though, the part that cuts into the wing as shown in Figure 12. This fairing can be installed now or after sheeting the top at the builder's option.

2.10 Sheeting the Upper Center Section

Sheeting begins by covering the flat areas. Most of the upper surface is flat enough to sheet in sections.




Figure 13: Sheeting the Center Section

2.11 Strip Planking the Engine Covers and Canopy Area

Figure 14 shows the right side with all areas sheeted that can be done in sections without strip planking. The left side in the picture has already been strip planked. The areas with no sheeting on the right side are the areas that have to be strip planked.



Figure 14: Preparing for Strip Planking the Engine Covers and Canopy Area

If you've never done strip planking before, have no fear, it's not that difficult. It is, however, very time consuming. It is unfortunately the only way to sheet a compound curve area with balsa.

A fiberglass or clear canopy is available as an option. If you use one of these, you can skip strip planking the canopy area.

Cut strips $\frac{3}{16}$ " or so in width, alternating straight and beveled cuts so you end up with an assortment of bevels to suit the curvature at hand. It helps you hold and anchor the strips at the formers to get a smooth curve. You will end up having to custom shape some of the strips, especially as you get down to the end. A Dremel belt sander makes this a lot easier.

The finished product should look something like Figure 15.



Figure 15: Finished Upper Center Section Sheeting

You can make your own fiberglass hatch later by finishing this area with primer, waxing it and laying up fiberglass over it.

When the glue is dry, you can now remove the center section assembly from the jig. Don't sheet the bottom yet. We're going to frame up the outer wing panels first.

3 Outer Wing Panels

3.1 Laminating the Rib Doublers

Start by laminating the ply doublers onto ribs 3B, 4 and 5 with epoxy.




Figure 16: Laminating Rib Doublers

It helps to mark the doublers before removing them from the parts sheet so their location and orientation can be determined.

These glue ups should be done with epoxy since this is a high stress area. Be sure and make a right hand and left hand set for ribs 3B, 4 & 5. The doublers go in the **outboard** side for ribs 3B and 4, and on the **inboard** side for rib 5. See the plans.




Figure 17: Rib 3A, 4 & 5 Laminations

3.2 Laying Down the Ribs

The ribs are at an angle to the building board. This is so the ribs will end up square to the wing datum line which makes everything easier later. Just use one of the supplied jigs (inside (inboard) or outside (outboard) – whichever you prefer) and attach the ribs to the building board using the “feet”. See Figure 18. Make sure to align ribs 3A, 4 & 5 **carefully** so that the slots for the spar tongues are in a straight line. Sight down from the top to align these over the plans. Use a scrap piece of 1/8 ply to ensure this alignment before going any further.

The ribs should lean outward toward the wing tips. You can glue some 1/8” or 3/16” square stick scraps to the feet to make pinning them to the building board easier. They'll be less prone to splitting also. Pin down the ribs from the root out to rib #11 and then install the elevon conduit (optional) before pinning down the remaining ribs. There are enough holes in the ribs that feeding a servo wire through shouldn't be a problem, but if you want a sure fire path then install a conduit. The prototype in the photos was built on a glass sheet over the plans, which is why you don't see any pins.




Figure 18: Laying out the ribs on the building board

3.2.1 Elevon Servo Conduit

Install the conduit into the holes cut into the ribs. Rolled butcher paper or old plans make an excellent conduit. This conduit just makes fishing the elevon servo leads through the wing easier. They aren't absolutely necessary. Now pin down the remaining ribs.

3.2.2 Drag Rudders

These weren't installed on the prototype model. If you plan to install them, start planning their installation now. The plans show their location.

3.3 *Installing the Laminated Spars*

The upper spars have significant curvature, so they are laminated from two pieces of 1/8" x 1/4" balsa. Start with the front spar. Note that the first (bottom) piece extends only to rib #18. Also mind the alignment of rib #3A. It is very important that rib #3A be straight and true, as this is the mating surface with the center section. Check its alignment frequently with the rib jig and a straightedge fore to aft.

Lay the first piece of the front spar into the notches and tack it in place. This piece will fix the

alignment of rib #3A, so install it carefully. The spars are curved near the root, so make sure you glue them down all the way into the notches. The second piece extends all the way to the wing tip. Lay a bead of thick CA on the first piece and glue the second piece down.




Figure 19: Installing the forward laminated spar



Figure 20: Installing the rear laminated spar

Repeat for the rear spar. Note that the bottom piece of the rear spar only goes from rib #3A to rib #7. See Figure 20.



Figure 21: Leading edge installation

3.4 Leading Edge, Shear Webbing & Sheeting

Install the 1/4" x 3/4" leading edge. The LE tapers significantly, so you will need to laminate some extra 1/4" pieces on the root side. Just make sure you have it thick enough to reach the edges of the ribs all along the top. There is a spliced piece at the wingtip, bevel it using the plans for reference. The LE is curved, but don't bend the balsa LE as you may induce a warp. Just let it follow its natural shape and laminate extra pieces as necessary to cover the front of the ribs. See Figure 21 and Figure 22.




Figure 22: Finished Leading Edge

Bevel and sand to the LE to match the rib contour. A mouse sander works great for this. Give the entire upper wing a light sanding. Install shear webbing as shown on the plans. Sheet the top of the panel using 1/16" balsa and your preferred method. The curvature of the upper surface makes the sheeting job a bit tricky. Take your time, it may help to sheet it in sections, for example, sheet the area between the two spars first. If you plan to install flaps, glue in the upper flap sub-spar as shown in Figure 23.



Figure 23: Upper flap sub-spar installation




Figure 24: Sheeting the upper outer wing panels

If you're using 36" sheeting, you will have to splice some extra sheeting at the wingtip as shown in the illustration as 36" sheeting is not quite long enough. You can use 48" sheeting to avoid this, but you'll

end up wasting a lot of wood.

The rear spar will need to be shaped between ribs 18 & 19. Sand it down even with the ribs.

Make sure you get good contact between the ribs and sheeting **everywhere**. The shape of the wing near the root contains compound curves. The shape is actually concave at the root of the upper surface near the TE. This is because of the reflex in the airfoil and is very important.

Also make sure you have enough sheeting overlapping the trailing edges of the ribs by at least 3/4". You will trim back the TE later to 1/2" past the rear tip of the ribs.




Figure 25: Starting on the bottom of the wing

When the glue is dry, remove the wing from the building board and flip it over. It should look something like Figure 25. Trim the "feet" from the ribs. The feet are perforated, so you may be able to gently break them free, but it is advisable to at least score through one side with a hobby knife first to make sure it breaks cleanly.

4 Completing the Outer Wing Panels

4.1 Upper Center Section Jig

The other two center section jig pieces are for holding the center section upside down (bottom up) and aligned while the lower formers and sheeting are installed. Assemble these two jig pieces. You can use them to hold the center section while fitting the outer wing panels and later sheeting the lower surfaces of the center section itself.

4.2 Fitting the panels

Trim the sheeting and spars at the root rib and sand smooth. Slide the outer wing panels by the spars through the slots in ribs 3B, 4 & 5. Make sure that you have a good fit and that the mating surfaces at 3A & 3B fit well. Sand/shim until you achieve a good fit. Don't glue them yet!

4.3 Determining Attachment Method

The all wood model wasn't really designed for removable outer wing panels. It can be done, but will require some extra work and added weight. If you want to go that route, contact us and we can advise you. You will have less work and a lighter model if you attach them permanently.

4.4 Jigging the Outer Wing Panels

Separate the outer wing panel(s) from the center section. After sheeting the bottom of everything you can finish fitting them to the center section. You will now be using the opposite wing plan to fix the "wash" (twist) of the wing while attaching the lower spars and sheeting the bottom. At the lower left of LP02 (lite ply parts sheet #2) are five jig pieces sized to fit the sheeted top surface of the outer wing panels. These pieces will be used for both outer wing panels. Attach them to the building board over their respective rib outlines. They should be marked by the laser, but if the markings aren't clear, match them up to the ribs on the plans. They should go on ribs 3, 7, 11, 15 & 19. Use the rib jig to attach these at the same angle as you did the ribs earlier. Once again some "feet" made of scrap balsa may be helpful in pinning these down. Test fit the wing in place as you build the jig. See Figure 26.

If properly constructed, this jig will allow you to build in the correct one degree of washout.



Figure 26: Attaching the wing jig to the building board

If you plan to install drag rudders, cut out the opening in the sheeting for the upper drag rudder now. It's easier to do this before the lower sheeting is in place.

Now place the wing upside down in the jig. Align the root and tip ribs with the jig and secure it in place. See Figure 27.




Figure 27: Attaching the wing to the wing jig

Now shape the bottom of the LE to match the rib contour. Install the lower laminated spars in the same way you did the upper spars. Sand the trailing edge to match the rib contour. You should end up with a sharp trailing edge. A mouse sander is a good tool for this.

4.5 Elevon Servo Installation

There are many ways to install servos in a wing. Rails and a mounting plate are provided from lite ply. It is recommended that you install the elevon servo between ribs 10 & 12. There is a horn built into the hinge on rib #11, so you should plan your pushrod installation accordingly.



Figure 28: Installing servo rails

Figure 28 Shows the servo rails installed in the first prototype between ribs 10 and 11. A standard servo will just barely fit in this space. The plans now show an installation across two rib bays, #10 - #12. The single bay installation was too cramped. Using two bays will make servo installation and access much easier. See the plans.




Figure 29: Servo tray installation

Figure 29 shows one possible servo tray with spruce rails for servo mounting. You can also just attach the servo to the tray using double-stick tape or glue.



Figure 30: Elevon servo installation

The servo is shown in place in Figure 30. The pushrod should be attached on the bottom and lead upward to exit the top sheeting near the horn on rib #11. The installation shown in the pictures is very tight and a bit hard to work with. The plans and parts have been modified for a larger hatch that goes over two rib bays. This will make the servos easier to access.

When you are satisfied with the elevon servo installation, you can sheet the lower wing. You will have to cut an access hatch later.

4.6 Drag Rudder Construction (optional)

The following shows the construction of scale drag rudders. These look good and are very effective, but they are also difficult and time consuming to build and set up. A simpler version is possible by simply hinging them at the skin line much like spoilers on a glider. We are told these are just as effective, but they haven't been prototyped on this model.

Start by laminating the drag rudder framework pieces with carbon fiber veil and thin CA. Make a torque rod from doweling or carbon fiber rod (recommended). Start with the upper drag rudder. Glue the arms (3) to the torque rod using epoxy. There are two arms for the rudder itself and a third small one (not shown in the picture below) for the pushrod. Make the upper drag rudder in the same way.




Figure 31: Drag rudder framework

Plan the servo installation. Micro servos will fit between the spars and the leading edge. The push rod should be perpendicular to the torque rods.

The torque rods should be fixed in place somehow so they don't slip sideways. We filed a groove into the torque rod and used small metal clips to hold it. See.



Figure 32: Torque rod clips




Figure 33: Drag rudder baffle and stop blocks

Now fit and glue the baffle between the two arms as shown in Figure 33. Also shown in are stop blocks. These are made from soft balsa and are necessary to keep the drag rudders closed. As we'll see, a rubber band or spring keeps them closed, the pushrod pushes them open.

Check the movement of the drag rudders. Make sure they clear each other and there is no rubbing or binding. Make the pushrods as shown on the plans. Cut two 1/8" dowel pieces 3/4" long. Drill 1/32" holes in each end as shown. On the servo side, the push rod will slide in and out of this hole. This allows you to use a standard servo setup as for ailerons. Only the "push" side will cause the drag rudder on one side to deploy. The "pull" side will do nothing since the pushrod will just slide partway out of the hole. You can use springs or rubber bands to pull the drag rudders closed. We chose to use rubber bands stretched around the pushrods as shown in Figure 34.



Figure 34: Completed drag rudder installation with servo and pushrods

Note that there are hatches cut in the lower skin, making the whole installation serviceable. You can see the hold-down blocks with screw holes in Figure 34. Also note that most of mid-section of Rib #16 has to be cut away.

4.7 Lower Outer Wing Panel Sheeting

Before sheeting the bottom of the outer wing panel:

- ⑩ Check the spar tongue slots by test fitting a scrap piece of 1/8 ply to ensure they are straight and unobstructed.

- ⑩ Install 3/32 shear webbing on front or rear spars as desired. It is recommended to install it on the front spars, at least out to rib #15.
- ⑩ Install the elevon sub-rib 10E. This allows sheeting support for the inboard side of the elevon. Also install the flap sub-ribs 7F for the same purpose.
- ⑩ Push a pin through the upper sheeting to mark the location of the rear spar where the elevon will be cut out later. You can make the cut much more accurate that way. Do this also around the elevon servo rails on the inside of ribs 10 & 12. After the wing is done, you can use a long pin to poke through and mark the location of ribs 10 & 12 on the bottom sheeting to facilitate cutting out the access hatch. Do the same for the flaps and drag rudders if you are installing them.
- ⑩ Check the outer wing panel attachment method and any block installation.
- ⑩ Make sure you have some way to run the elevon, flap & drag rudder servo wires.
- ⑩ If you have installed drag rudders, check their installation one more time before sheeting.
- ⑩ If you plan to install flaps, make sure the flap sub-spars are in place. See the plans.

Sheet the bottom of the wing like you did the top.

Now repeat the whole process for the other outer wing half.

5 Installing Fans & Electronics

5.1 Fans

With the center section in it's cradle (jig), test fit the fans and plan for access once the lower surface is sheeted. You will need to make hatches to access the fans and speed controllers. Plan your wiring layout. There are some excellent articles on <http://www.warbirds-rc.com> showing methods of EDF installation. I recommend you study some of those before attempting this if you've never done it before. Figure 35 shows the installation of fans and tubes in the prototype model, which used the fiberglass center section. The framework is different, but the fan installation is the same as for the all-wood version.




Figure 35: Installation of fans and tubes




Figure 36: Close-up of fan and tube installation

5.2 Batteries

Plan the installation of your LiPo batteries. There is space for them between ribs #1. If you're building the all-wood version, you may want to cut away much of Rib #0 to make installation and access easier. Be careful that you leave enough structure to support the skin in the cockpit area. Velcro is a good way to attach the batteries. The square holes in the forward carry-through spars are there to allow the fore and aft movement of the batteries to achieve the correct CG. You might want to install velcro across this entire area so this movement will be easier to do at the field. You can glue thin sheet plastic to the ribs with thick CA and stick the velcro to that.




Figure 37: Installing velcro on Ribs #1

Figure 37 shows such an installation of velcro using sheet plastic. This photo is of the framework for the fiberglass center section, but the velcro installation is the same.

Unless you keep the structure aft of the CG extremely light, you will most likely end up with the batteries nearly all the way forward. You can always use the additional velcro for the installation of other components such as receiver, switches, etc.

5.3 Connecting it all Together

Depending on the speed controller you choose, you will need to decide whether to use its BEC or not. Check the instructions that come with your speed controller. Depending on the motors and the current they draw from the main batteries, a BEC may or may not be appropriate. It is generally safer to run the receiver from a separate battery in a high power application, and that is what we've done with the prototype model. To do this, just cut the positive (red) lead from the speed controller to the receiver and connect a receiver battery to the receiver in the conventional way.

5.3.1 Battery Connection

There are two ways to connect the batteries to the speed controller. Each battery can be connected to each speed controller independently. Some prefer this kind of installation since faults will be isolated to one side or the other. However, any differences in current from the batteries will cause an imbalance in power output from the fans. For this reason many prefer a parallel connection. This way both speed controllers always see the same current from the batteries. This is the method we chose for the prototype model and it has worked well. A diagram showing parallel connection between the

ESCs and Batteries is shown in Figure 38 below. It is actually very simple, just connect all of the positive (red) wires together and all of the negative (black) wires together. It's up to you how and where to put connectors. It is usually convenient to be able to separately connect each battery and ESC, which is why the parallel adapter shown has connectors at both ends.




Figure 38: Parallel connection diagram

A photo of this installation in the finished prototype model is shown in Figure 39.




Figure 39: Electronics installation in the prototype model

5.3.2 Rear Duct

See the plans. There is a template on the plans for cutting out the rear duct. A good material for the rear ducts is 5 mil mylar. Cut out the duct, roll it up and insert it through the duct brackets. Let it expand and use a few pieces of tape to hold its size. Remove it and use clear packing tape to permanently tape it together.

The warbirds-rc articles show how to make and install a rear duct. See <http://www.warbirds-rc.com>. Because ours will be rather long, you'll need to devise a method for installing it from the rear. It would be best to do that now while you have easy access to everything. We found that a piece of doweling 22" long or so makes this job easier. Use the dowel to collapse the clear plastic rear duct tube after it is taped together. This makes it small enough to fit through the duct brackets easily. Fitting the duct around the speed controller and mating it to the fan shroud is a bit tricky. It gets easier with some practice.

Once you've installed all interior equipment and planned for all necessary access, we can move on to sheeting the lower surfaces.

6 Lower Center Section

6.1 Lower Center Section Sheeting

Attach the upper center section jig pieces to the building board as shown in Figure 40. These jigs are sized to accommodate the sheeted center section. It won't fit if the upper center section sheeting isn't in place.




Figure 40: Upper Center Section Jig




Figure 41: Upper Center Section Jig - Viewed from Below

You should position the jig so that at least one outer wing panel can be fitted to the center section without moving the jig. It would be best if both panels can be fitted without moving the jig, but this may not be possible. In that case you will need to remove the center section (with jig) from the building board and turn it around so that you can fit the other outer wing panel. Figure 41 Shows how

things should look at this point.

If you want to achieve scale fairings, you'll need to use the supplied template to get the right shape of the rear fairing that covered the main landing gear. I would recommend using foam for the compound curve areas of these fairings.

Figure 42 shows most of the flat sheeting installed and the outlines of the rear fairing marked on the balsa using the templates.

Use foam blocks, curved sheeting or strip planking to fill in the rest of the shape.




Figure 42: Lower Flat Sheeting Installed

The aft parts of the fairing can be sheeted with flat sheets as shown in Figure 43. The sides of this fairing are stripped planked as shown.



Figure 43: Aft Lower Fairing Sheeting

6.2 Wing Tips

Using the supplied templates, make some wing tips out of scrap balsa or foam and attach. Rough shape the LE, TE and tip.

6.3 Cutting out and Hinging the Frise-style Elevons

Hinges are supplied for a Frise-style control surface. See the diagram on the plans. This style is helpful for this model. The Frise-style elevons aid in turning. By creating drag on the down wing, they help eliminate so-called “adverse yaw” which causes the model to yaw in the direction opposite the turn. Since a flying wing lacks a vertical surface to compensate for adverse yaw, this is the only method. If you're going to fly the model using a bungee and belly land, however, I would recommend conventional elevons. This is because the frise-style elevons protrude downward and tend to catch on the ground. If you use conventional elevons, however, you **must use differential** for the model to turn properly.



Figure 44: Frise elevon construction

Using the plans and/or the marking and wingtip templates for reference, mark the elevon outline on the wing skins. Cut them loose, making the forward cut right at the edge of the rear spar. See the rib plan for reference. Once the elevon is cut loose, make a second angled cut through through the top surface of the elevon and ribs, further back at the parting line shown on the plans. Sand the cut edges smooth on both the wing and elevon. Once this is done you can add the LE sheeting on the elevon. The hinges, made of 1/16" ply, should be reinforced by laminating 3-4 oz. fiberglass cloth or carbon fiber veil on both sides. Carbon fiber veil (tissue) is available from <http://www.cstsales.com>. Test fit the hinges on the wing. You will have to slide these into the wing sideways and then turn them upright against the rib.

You will need to cut slots on the bottom of the elevon to install the hinges. The inboard hinge will also need a slot on the top for the horn. You can offset the hinges on either side of the ribs as shown on the plans, or you can use a 1/16 balsa spacer on either hinge and attach them to the same side of the rib. The latter is probably better. The hinges should be aligned properly and should not need a shaft that goes through all of them. There are many ways to hold the hinges in place. Small holes are pre-drilled by the laser. Cotter pins can be used, or 2-56 screws with nuts. If you choose the latter, secure the nuts with thread locker or they will vibrate loose. Install the 1/64" ply hinge cover on top of the wing to cover the gap left by the elevon hinge area. See the plans.

You can now hook up and test the elevon servo.

6.4 Flap Construction (optional)

Flaps on a flying wing have to be used in either “split” or “crow” mode. Crow mode means that as the flaps are deployed downward, up elevon is required to keep the nose up. This has been tried and found to be ineffective. Split mode is recommended. This means that on each side, one flap goes down and the other goes up. On the prototype, we have the inner flaps going down and the outer flaps going up. This is really just using the flaps as speed brakes. It is effective in slowing the plane for landing. Plan your flap and radio installation accordingly. Start by cutting out the flaps. You should have pinholes to use as a guide to mark the cuts. Use 1/8 or 3/16 balsa to sheet the faces of the flaps as shown in Figure 45.




Figure 45: Elevon & flaps get their face sheeting

Laminate the flap hinges with carbon fiber veil as shown in Figure 46.



Figure 46: Flap hinges laminated with carbon fiber veil



Figure 47: Inboard flap hinge

Glue hinges into the wing and flap, aligning them carefully so the holes and hinge line are true. Secure with a pin or bolt. Check the action and install the servo and pushrod. Remember that the servos should face the same way (right or left) on either wing, not opposed as with ailerons. Otherwise you will need an in-line servo reverser for one of the servos.

Basic construction is now complete. Install the outer wing panels on the center section, stand back and soak it in. WOW!!!

7 Finishing

7.1 Finishing the Center Section

Since EDFs are still not the most efficient power plants, weight is critical in an EDF model. It is therefore recommended that you consider your finishing methods carefully. For the center section, a very lightweight filler should be used. The smoother the surface is before finishing, the lighter the finish will be. The following layers are heavier. Cover with a very light ($\frac{1}{2}$ or $\frac{3}{4}$ oz) fiberglass cloth and resin thinned 40-50%. Only one coat of resin is needed, you just need to firmly stick down the cloth. Follow this with automotive primer and spot putty. Continue sanding and filling/priming until smooth. Any paint can be used over that.

7.2 Finishing the Outer Wing Panels

We have had good results using Nitrate Dope instead of epoxy and primer for finishing the outer wing panels. This method is much lighter, but still uses $\frac{1}{2}$ oz fiberglass cloth and is very strong. This method is detailed on RCSCALEBUILDER.com in the finishing forum. Keep in mind that the majority of the surface area of the model is **behind** the CG, so the weight of the finish has a big impact on the final weight. Using the nitrate dope method, we didn't need any ballast at all in the nose.

7.3 Paint & Markings

Many different paints can be used. Since this is an electric model and fuel proofing is not required, you might consider using paint for plastic models as these come in very accurate colors and are readily

available in any well stocked hobby shop. The Ho 229 V3 was never painted at the factory, but if it had been, it would have most likely been painted in RLM 82 Dunkelgruen upper surfaces and RLM 76 Lichtblau lower surfaces as the V1 and V2 were painted. If the Ho 229 had entered production, it would have most likely been painted in the same colors as other jets of the time, namely a splinter pattern of RLM 81 Braunviolett and RLM 83 Lichtgruen upper surfaces and RLM 76 lower surfaces.

For markings, you can use whatever stick-on markings you can find, but they won't be accurate. I encourage you to use the marking templates supplied. It's a little more work this way, but the results are worth it.

You can just cut these out and use them as masks directly. Just tape and hold them down on the wing and spray the markings on. If you're careful, you'll only get a little over spray which won't be noticeable from a distance. If you want cleaner lines, a good way to use these is to use 3M 77 spray adhesive to glue the templates to frisket paper or other adhesive backed paper with a low-tack adhesive. 3M 77 leaves a residue, so it is not recommended to use it to attach anything directly to the model. You can then cut through the outlines of the *Balkankreuz* which will yield easy to use (and reusable) paint masks.

8 Trimming for Flight

8.1 Extension Tubes

Extension tubes on the exhausts are required for flight. The exhaust from the EDF units creates a vortex-like turbulent airflow. Since the exhaust exits over the rear of the wing on the Ho 229, this causes a yawing moment and general instability. The first prototype of this model crashed for this reason.

All successful test flying to date has been done with the extension tubes shown in Figure 48. It is hoped they can be reduced in size to be less noticeable, or eliminated altogether with the use of stators. This work has not yet been completed. As you can see from the flight video, the tubes aren't noticeable in the air.



Figure 48: Exhaust extension tubes

8.2 *Center of Gravity*

The CG needs to be measured and determined carefully. The CG is more sensitive on a flying wing than a conventional aircraft.

It is best to start out with a CG $1/16''$ - $1/8''$ forward of that shown on the plans. Be sure to also balance the model laterally. If you have built the model according to plan and your equipment installation is more or less symmetrical, you should not need much lead in the wing tips. If you're putting more than an ounce or two, there is probably something wrong with your balancing method!

8.3 *Balancing Method*

Do not attempt to balance the model by suspending it from a rope. This method is not reliable. Use a carpenter's square or similar to measure the CG location. Make sure you are measuring from the tip of the nose, parallel to the datum line of the airfoil (the datum line is the line from the leading edge to the trailing edge). Mark the CG location on the bottom of the wing on either side of the nose gear fairing. This should be exactly 13 inches from the nose.

We have constructed a balancing jig which works very well. It measures the CG very precisely and is repeatable. The idea is to rest the model on two pegs at the desired CG point and use the tail as a "meter" to determine the balance more precisely. See Figure 49 for a conceptual illustration.

Measure and mark the CG as outlined above. Drill a small hole on each side. Cut two pieces of 1/2" wooden dowel, sharpen them and make a balancing jig similar to what is shown in Figure 50. The jig (base board) must be leveled in order to make the readings consistent.

The model is very tolerant of a forward CG. You will just have to hold 'up' elevon to keep the nose up which results in increased drag, but otherwise the model will fly fine. Extreme nose heaviness makes the model 'mush', so don't go overboard.

We are still fine tuning the balance of the second prototype, so stay tuned to the Yahoo group and the RCSCALEBUILDER thread for the latest balance info. If you follow instructions to the letter, you should be able to start your flying with a near optimal CG.






Figure 50: Balancing Jig (example)

Move the LiPo batteries until the correct fore/aft CG is established. You will be able to tell when you have achieved the correct CG by the trims. The model is balanced correctly when it will fly straight and level at $\frac{1}{2}$ throttle with the elevons neutral to $\frac{1}{16}$ " up. It is best to start with it a bit nose heavy and gradually shift the CG aft. Don't go too far nose heavy though, as the model doesn't fly well if it is drastically nose heavy. You will struggle to keep the nose up and it will "mush" instead of "fly".

8.4 Recommended Control Throws

Start with $\frac{1}{2}$ " down and $\frac{3}{4}$ " up throw on the elevons, for both elevator (elevons working together up/down) and aileron movements. You can experiment with varying these, but we have found them to work well.

8.5 Ground Sit (ROG version)

The model should sit with only a slightly positive incidence on the ground. In other words, if you measure from the ground to the leading edge and trailing edge at the outer wing panel break, the leading edge should be only slightly higher, $\frac{1}{4}$ " or so. The scale ground sit has been tried and found not to work. It causes the model to become airborne too soon and to bounce severely on both takeoff and landing. We suspect this is because the model has much lighter wing loading than the full size.

9 Flying the Ho 229

9.1 General Flying Characteristics

In general, the Ho 229 handles much like any other plane. Though much has been written about instability of flying wings, you will likely be surprised at just how well it flies. The Horton brothers spent many years building and flying pure wing designs. The Ho 229 was the culmination of all of that learning and is an excellent design given what was known at the time.

9.2 Aerobatics

The Ho 229 is quite capable of aerobatics. Depending on power available, the model should be able to do all the basic maneuvers. Riskier maneuvers such as “provoked” spins have not been attempted and are not recommended.

9.3 Bungee Flying

If you're going to fly the Ho 229 with a bungee, make sure you have a field large enough. If you have a clear approach with no trees or other obstructions, the field must be at least 200 yards long. If there are obstructions, it should be 250-300 yards long at least. Assuming you have no speed brakes or flaps, it takes a long approach to slow the Ho 229 for landing.

If you have a field available with tall grass, this can be the easiest way to recover the Ho 229. Just make sure it is thick enough to do the job. If it is sparse you may be in for a hard landing!

Mount your bungee hook halfway between the nose and the CG. Make sure that whatever hook and ring combination you use will separate cleanly on launch. If you're new to bungees, I would highly recommend experimenting with something expendable before launching the Ho 229.

Starting with a few unpowered launches is advisable. For a seven pound Ho 229, we found that 30 lbs pull on the bungee gave a good short glide. For launching with the intent to fly, we used 35 lbs. A marine fishing scale can be used to measure the pull on the bungee. Don't guess!

9.4 Flying from a runway (ROG)

The model should be close to zero incidence while at rest on the ground. If the nose is too high, it will want to fly before it's ready, and it will tend to bounce on landing. Some have devised a variable length nosewheel strut which helps. This allows a negative incidence (shorter strut) on landing, which eliminates the tendency of the model to float or bounce.

9.4.1 Takeoff Procedures (ROG version)

We have discovered that the model needs **full up-elevon during the takeoff roll** in order to relieve strain on the nosegear. If you don't do this, the model is likely to flip over on takeoff. Also, the nosegear is likely to bear side loads. The nosewheel should have smooth bearing surfaces on both sides, either wheel collars or a washer soldered to the axle. This is very important. If the nosewheel binds on any side load, the model is likely to flip over if it veers.

9.5 Approach and Landing

Flying wings such as the Ho 229 have a tendency to “float” on the cushion of air next to the ground (“ground effect”). Plan accordingly and leave yourself plenty of overrun. It's important to bleed off as much speed as you can on approach. Use a gradual descent. Hold the model just off the ground

until it stalls. This will require more and more “up” elevon until, by the time you reach stall speed, you will probably need full “up” on the stick. If you're flying off of grass with no landing gear, this is especially important. If you “fly” the Horton onto the grass, it will bounce and flip over. Damage is usually minor, but you can avoid this with the right approach technique.

It is thought that the scale drag rudders will be useful on approach. They can be mixed with the flap channel and used together as drag brakes. Belly landings would have to be done carefully to avoid damaging the lower drag rudders however. This configuration has not been tested to date.

9.6 *More Info*

9.6.1 RCSB Thread

Go to <http://www.rcscalebuilder.com> and register. It's free and worth your trouble. Trust me. The Ho 229 thread(s) are in the “Scratch Builds” forum.

9.6.2 Yahoo Group “Ho229”

Go to <http://groups.yahoo.com/group/ho229/> and join the group. This is a good place to post questions and connect with others building the Ho 229. The building guides are also posted here in PDF format.

9.6.3 Ezone Thread

Paul Sforza, one of the Ho 229 beta builders, has started a beta build thread on the RCGROUPS Ezone: <http://www.rcgroups.com/forums/showthread.php?t=718124#post7863730>

9.6.4 Phone and “Snail Mail”

Finally, if you don't have Internet access and need help, feel free to contact us by letter or phone. The address and phone number are listed on the title page of this building guide.